


91-162 Function schematic seat back locking system (coupe)



— Suction line  
— Control line

8 Check valve  
10 Restrictor  
11 Distribution piece  
17 Connection piece  
22 Distribution piece

44 Door contact vacuum switch  
46 Vacuum switch (driver's seat back)  
51 Vacuum element (seat)  
54 Operating rod  
73 Intake manifold

